

# CRANE-II

## Operating Manual



TBL-series

TBS-series

# INDEX

1. INTRODUCTION -----	3
2. MAIN FEATURES -----	3
3. TECHNICAL SPECIFICATIONS -----	4
4. DISPLAY & KEYS -----	6
5. USE OF BATTERY CHARGING -----	7
6. GENERAL FUNCTIONS -----	8
7. SETTING MODE -----	9
8. SELF TEST MODE -----	14
9. INFRARED REMOTE CONTROL -----	16
10. OPTIONS -----	17
11. ERROR MESSAGE -----	20

## 1. INTRODUCTION


This Service and Operation Manual are the specifications for our **TBL/TBS**. The **TBL/TBS** is the product of years of design, development, and in-field testing. This **TBL/TBS** has been designed with reliability, under rigid quality control and with outstanding performance.

This **MANUAL** included with basic technical information about composition of hardware and programmatic functions.

### ■ Precautions

Please check if the safety hook is connected well before you install our **TBL/TBS**, so that the **SHACKLE** is not separated.

- ◆ Don't install the **TBL/TBS** in direct sunlight.
- ◆ Avoid sudden temperature changes, vibration, wind, water, or excessive dirt.
- ◆ Avoid from the shock of excessive weight.
- ◆ Place the scale away from water.
- ◆ Use away from heavy R.F noise.




## 2. MAIN FEATURES


- ◆ Very light and Sturdy Aluminum Alloyed Case
- ◆ Very easy-to-read => Downward Display
- ◆ Standard Remote control
- ◆ One-Touch Battery Pack (90 degree)
- ◆ Lithium Polymer Rechargeable Battery Pack
- ◆ "Hold" (Manual or Automatic) function
- ◆ Rotating Hook
- ◆ Weight-Adding Function => Only possible in our optional remote control
- ◆ RS232C Serial Communication (option 1)
- ◆ Wireless Communication & Wireless Printer (option 2)

### 3. TECHNICAL SPECIFICATIONS

#### ◆ Overall View



#### ◆ Size




Model	Max.	e=d	Dimensions				Weight
			H	A	W	B	
TBS/TBL-1T	1000kg	0.5 kg	407	62	50	25	8.9kg
TBS/TBL-3T	3000kg	1 kg	525	73	57	34	15.2kg
TBS/TBL-5T	5000kg	2 kg	525	73	57	40	16.7kg
TBS/TBL-10T	10000kg	5 kg	697	101	83	55	26.9kg


◆ Specifications

MODEL	TBS-series	TBL-series
Display	5 digit LED (Character Size 30mm)	5 digit LCD (Character Size 40mm)
Display lamp	LOW BATTERY, ZERO, TARE, HOLD	
Temperature	-10℃ ~ 40℃	
Function	ON/OFF, ZERO, TARE, HOLD, *	
Maximum tare weight	Full Tare	
Zero point	Within 2% of Maximum Weight	
Initial zero band	Within 10% of Maximum Weight	
Battery time	About 100 hr	About 200 hr
Nominal voltage	DC 7.4V	DC 3.7V
Rechargeable adaptor	DC 12V, 1A	DC 5V, 1A
Assembly	Manual 1EA , Battery pack 2EA Rechargeable adaptor 1EA , Infrared remote control 1EA(OPTION)	

◆ Part list



[Crane scale]




[Rechargeable adaptor]



[Infrared remote controller]

## 4. DISPLAY & KEYS



### ◆ Display Description

<b>-88888</b> .kg	Displays the accurate weight
<b>○</b>	Displays that weight is Stable
<b>ZERO</b>	Displays that current weight is Zero
<b>TARE</b>	Displays the net weight, when the tare is included
<b>HOLD</b>	Used to weigh an unstable or moving thing
<b>BAT</b>	Displays when a battery has to be recharged

### ◆ Key Function


Key	Description	
	ON/OFF	Turn on and off the scale
	ZERO	Reset scale to zero
	TARE	Input a tare weight
	HOLD	Weigh an unstable and moving thing (Manual / Auto)
	ENTER	Testing Mode or Returning a new Mode

## 5. USE OF BATTERY CHARGING

### (1) Method of recharge battery

- Check the power supply voltage.
- If adaptor is still being charged, the RED lamp is on.
- If a charging is completed, the RED lamp is off.

The battery charging time takes about 6 hr. (The battery charging time is subject to be changed according to battery condition.)



### (2) Method of exchange battery pack

- a. Turn clamps that exit on both sides of charger to the right in a quarter
- b. Pull out a battery pack
- c. Inserting is in reverse

### (3) Battery pack specifications

Nominal capacity	4000mAh
Nominal voltage	7.4V
Dimensions	125 * 68 * 12 (mm)

### (4) Low battery lamp

In order to prevent the electric discharge, after **LOW BATTERY LAMP** is on, the power will be turned off automatically after about 1~5 hours.

(It's subjected to be changed according to using conditions.)

## 6. GENERAL FUNCTIONS

Press the **ON/OFF KEY**. The scale & RF indicator will perform RF self-test on Weight Display and will be ready to RF communication.

### (1) Zero function

Use to correct drifted zero value when the scale is unloaded, and motion is not detected.

This function works when **ZERO KEY** is pressed, and the **ZERO LAMP** is on.

### (2) Setting tare weight function.

Press the **TARE KEY**. Then, the scale will memorize the weight of the tare and will display zero value '0'kg. The **TARE LAMP** will be on.

To escape this function, remove everything from the scale, and press the **TARE** or **ZERO KEYS**.

Then, the **TARE LAMP** will be off and this function is terminated.

### (3) Hold function

#### Automatic hold function

- Press **HOLD KEY** when the scale is empty (Initial Zero State).
- The weight display will indicate **HH□□**. **HOLD LAMP** is on.
- After loading a thing, if the weight turns stable then, a display shows **□□□□** and average weight will appear.
- The weight of a loaded thing is displayed.
- To escape the automatic hold mode, when zero point is on, press **HOLD KEY**.

Then, the message of **HHOFF** is displayed and **HOLD LAMP** is off and normal weighing mode is reverted.

#### Manual hold function

- Press **HOLD KEY** loading a thing.
- This message of **Hold** is displayed and sequentially the message of **□□□□** is shown with appearing the average weight.
- The weight of a loaded thing is displayed.
- To escape the manual hold mode, remove everything from a hook, or press the **HOLD KEY**. Then, **HOLD LAMP** will be off and the scale changes from a hold mode to a normal mode.






## 7. SETTING MODE

### (1) How to enter this mode

Press the **ON/OFF KEY** while pressing the **TARE KEY**.

### (2) Keyboard

-  : Use to set up an initial zero value (0).
-  : Used to increase the setting constant one by one.
-  : Used to save the setting constant changed and to move into normal mode.

### (3) Setting menu (F1 – F18)

- F01 : Adjustment the speed of weight change (1 ~ 9)

Setting Menu	Description
F01-1	Very fast
F01-5	Normal
F01-9	Very slow

- F02 : Weight Storage Function

Setting Menu	Description
F02-0	Not used
F02-1	Use

- F03 : Adjustment the hold speed (1 ~ 9)

Setting Menu	Description
F03-1	Very fast
F03-5	Normal
F03-9	Very slow

■ F04 : Stable condition set of weight (1~9)

Setting Menu	Description
<b>F04-1</b>	Sensitive
<b>F04-5</b>	Normal
<b>F04-9</b>	Insensitive

■ F05 : Time of Power Saving Mode

Setting Menu	Description
<b>F05-0</b>	Not used
<b>F05-1</b>	20sec
<b>F05-2</b>	1min

■ F06 : Automatic Zero Condition (00~99)

Setting Menu	Description
<b>F06-00</b>	No compensation
<b>F06-23</b>	Compensation for gradual change below 1 division for 3 sec.
<b>F06-99</b>	Compensation for gradual change below 4.5 division for 9 sec.

■ F07 : Auto Hold Start

Setting Menu	Description
<b>F07-0</b>	Manual
<b>F07-1</b>	Automatic

■ F08 : Initialization Hold Weight (1~9)

Setting Menu	Description
<b>F08-0</b>	Zero (0)
<b>F08-3</b>	Below 3 division
<b>F08-9</b>	Below 9 division

■ F09 : Function \* key **-option 1,2**

Setting Menu	Description
<b>F09-0</b>	Use to clear previously added weights.
<b>F09-1</b>	Print command key
<b>F09-2</b>	Weighing data send to computer
<b>F09-3</b>	Wireless print command key (include print format)
<b>F09-4</b>	Wireless print command key (only weight data)

■ F10 : Device number (Identification number of each scale) **-option 1,2**

Setting Menu	Description
<b>F10-0</b>	Device No.0
<b>F10-5</b>	Device No.5
<b>F10-9</b>	Device No.9

■ F11 : Item number (Identification number of each Item) **-option 1,2**

Setting Menu	Description
<b>F11-0</b>	Item No.0
<b>F11-5</b>	Item No.5
<b>F11-9</b>	Item No.9

■ F12 : Data set sent to computer **-option 1,2**

Setting Menu	Description
<b>F12-0</b>	No data output
<b>F12-1</b>	Command mode
<b>F12-2</b>	Transmission in an state of stable & unstable.
<b>F12-3</b>	Transmission only in stable state

■ F13 : Wireless real time communication -option 1,2

Setting Menu	Description
F13-0	Not used
F13-1	Auxiliary display
F13-2	TF200 (Wireless dongle)

■ F14 : Print line feed -option 1,2

Setting Menu	Description
F14-0	1 line feed
F14-5	6 line feed
F14-9	10 line feed

■ F15 : Print form -option 1,2

Setting Menu	Description
F15-0	Form 0 (serial No., Item No., weight)
F15-1	Form 1 (weigh No., Item No., weight)
F15-2	Form 2 (weight)

[FORM 0]

001, ID_9,	25 kg
------------	-------

[FORM 1]

SN_012, ID_9,	25 kg
---------------	-------

[FORM 2]

25 kg
62 kg

■ F16 : Initialization of number measured daily (weigh No.) **-option 1,2**

Setting Menu	Description
F16-0	Maintain current number
F16-1	Initialization (starting from No.1)

■ F17 : Auto print **-option 1,2**

Setting Menu	Description
F17-0	Not used
F17-1	Auto print (include print format)
F17-2	Auto print (only weight data)
F17-3	Wireless Auto print (include print format)
F17-4	Wireless Auto print (only weight data)

■ F18 : Hold data auto print **-option 1,2**

Setting Menu	Description
F18-0	Not used
F18-1	used

## 8. SELF TEST MODE

### (1) How to enter this mode

Press the **ON/OFF KEY** while pressing the **ZERO KEY**.

### (2) Self test menu (TEST 1 –TEST 6)

#### ■ TEST 1 : Keyboard test

	Key	Display	Descriptions
ZERO			If you push the button that you want to test, the key number is appeared on the display. If press the <b>ENTER KEY</b> , it moves into TEST 2.
TARE			
HOLD			
SUM			
ENTER			

#### ■ TEST 2 : Display test

Display	Description
	TEST 2 runs off automatically and a display is on. If press a <b>ENTER KEY</b> , move on TEST3.


#### ■ TEST 3 : A/D conversion test (Load cell test)

Display	Description
	The value is the conversion constant for A/D. The value may be different according to scale models. If a <b>ENTER KEY</b> , move on the weighing mode.

Please check if the displayed number is easily changed with giving force to a hook.  
If the displaying number is not changed or remains '0', then it needs the service after sales.

■ **TEST 4 : Not used**

■ **TEST 5 : RS-232C test -option 1,2**


Display	Description
	Ex) 49-13 : Transmit 49 (ZERO KEY) Receiver 13 (PC ENTER KEY) (ZERO KEY 49, TARE KEY 50, HOLD KEY 51)

■ **TEST 6 : Wireless communication test -option 1,2**

Press **ZERO KEY** at the scale. The numeric character increases on the auxiliary display.

## 9. INFRARED REMOTE CONTROL

### (1) How to use



- OFF KEY : Use to power off the scale  
(Power-ON is available only on scale.)
- ZERO KEY : Same as Scale keyboard
- TARE KEY : Same as scale keyboard
- HOLD KEY : Same as scale keyboard
- SET KEY (CLEAR) : Use to clear previously added weights.
- SUM KEY : Use to add weights.

If press a SUM KEY, the sum of weights is displayed. After that, about 2 sec later, a weighing mode is reverted.

### (2) Specifications

List	Description
Available Distance	6 m ~ 10 m
Available Angle	60°
Power	3V (1.5V AA 2 EA)



## 10. OPTIONS

### (1) OPTION 1 : RS-232C serial out

#### ■ RS-232C port connection

Connect serial port of the scale to serial port of PC as follows.

**(RED) TXD ----- RXD (2)**

**(WHITE) RXD ----- TXD (3)**

**(GREEN) GND ----- GND (5)**

[RS232C wire of JAC737]

[Serial port of computer]

#### ■ Data format

Type : EIA-RS-232C

Method : Full-duplex, asynchronous transmission Format

- ① Baud rate : 9600 bps
- ② Data bit : 8, Stop bit : 1, Parity bit : None
- ③ Code : ASCII
- ④ When data is sent to computer? Set in SET mode(F12).
- ⑤ Format (18byte)

Start Code		Blank	Lamp Status	Weighing data	Unit	Stop code			
S	T			, +/-	7byte	k	g	CR	LF
U	S	,							

- Start code : ST (Stable) / US (Unstable)

- Lamp status byte

Bit7	Bit6	Bit5	Bit4	Bit3	Bit2	Bit1	Bit0
One decimal point	Two decimal point	Three decimal point	Stable		Zero	Tare	Hold

- Weighing data (8byte)

a. 13.5 kg : '+', '.', '5', ' ', '1', '3', '.', '5'


b. -135 kg : '-', '1', '3', '5', ' ', '1', '3', '5'

**(2) OPTION 2 : Wireless communication**


**◆ Wireless specification**

RF frequency range	2400 ~ 2483.5 MHz
Output power	Max. 4dBm
Channel width	2 MHz
Frequency offset	< ±30ppm
Transmit data rate	250Kbps,500Kbps
Receiver sensitivity	-99dBm (PER <1%)
Maximum input level	0dBm
RF In/out impedance	50 ohm (TXRF, RXRF)
Spurious(2nd harmonics)	< -30dBm
Radio link effective range	Approx. 100M (Open space)

① Wireless auxiliary display (AD-8915F)



② Wireless auxiliary display (FJD-PLUS)




[standard]

[wall hanging]

[wall rotation]

[glass adhesion]


③ Wireless controller (TF-100)




③ Wireless controller (TF-400)



④ Wireless dongle (TF-200)



## 11. ERROR MESSAGE



■ Error 1

Message : Data in an internal storage allocation are erased owing to any electronic impact.

Management : Please contact us to resolve this technical problem.



■ Error 2

Message : Something wrong in a Load cell connection or in an A/D conversion.


Management : Please contact us to resolve this technical problem.



■ Error 3

Message : The initial zero range is exceeded within +/- 10% of maximum weight value.

Management : Please check if a hook is empty.



■ Error

Message : When a thing is over-weighed within the maximum weight value, the error message is displayed.

Management : Do not weigh the thing whose the limit of a maximum weight value is exceeded.

If a load cell is broken, then the load cell has to be replaced.